


Cable Tensioner Installation Guide - Industrial Winch / Hydraulic Winch




Following is the procedure to install the cable tensioner



0


Tools:

- a. Adjustable wrench
- b. Open end wrench (13mm)
- c. Allen wrench (5mm)
- d. Round bar (ϕ 4mm~ ϕ 6mm)





1

Using an adjustable wrench to push out the cable tensioner.




2

While pushing out the cable tensioner, insert the round bar into the ϕ 6.4 hole to hold it.




3

Remove all M8 screws, spring washers and nuts.




4

Align to the holes with cable tensioner and winch tie bar. Using a 5mm Allen wrench to secure four M8 screws.



5

On the reverse side, place M8 spring washer and M8 nut. Using a 13mm open end wrench to secure it.




6

M8 screw and nuts installation complete.



7

Slightly pull up the cable tensioner and pull out the round bar. Put down the roller with care to avoid finger injury.



8

Assembly complete.