COMEUP WINCH

Self-Recovery Winch

Model: *Seal Gen2 9.5rs*

PN: 295850 12V 295870 12V DC
295853 12V DC

Introduction

▶ Feature

Line pull:	4,309 kg / 9,500 lb synthetic rope first layer
Synthetic rope:	10 mm × 30.5 m (3/8"×100′) synthetic rope
Brake:	Patented cone brake holds full load
Clutch:	Turn the T-handle for rapid rope payout
Control:	Handheld pendant switch powers the winch

▶ Unpacking

- Winch assembly..... 1 pc
- Control box..... 1 pc
- Remote control..... 1 pc
- Synthetic rope with sling hook..... 1 pc
- Hawse fairlead..... 1 pc
- 1.8 m (6′) 2 gauge battery lead..... 1 pc
- Wireless Transmitter..... 1 pc

▶ Read this manual carefully

You should carefully read and understand this manual before operating it. Careless winch operation may result in personal injury hazards or property damage.

Installation

Before using the winch, make sure all electrical components have no corrosion or damaged; the environment should be clear and dry.

▶ Winch and hawse fairlead mountings

- It is very important that the winch will be mounted on a flat and hard surface of mounting channel in order to make sure the motor, drum and gearbox housing are aligned correctly.
- Hawse fairlead does not mount to the winch directly.



- The synthetic rope shall be wound in an under-wound orientation only.
- Four (4) M10 x 1.50 pitch 10.9 grade with 63.8 N-m torque settings (maximum) high tensile steel bolts must be used in order to sustain the loads imposed on the winch mounting.
- Two (2) M10 x 1.50 pitch stainless steel bolts must be used for fastening the hawse fairlead into the mounting channel.

▶ Wiring Diagram

- Connect thermal sensor harness plug, control ground, and cable A/F1/F2 to the motor.
- Attach the ground lead firmly to the negative (–) battery terminal and power lead to the positive (+) battery terminal. The voltage drop for the winch motor must not exceed 10% of the nominal voltage of 12V DC.



▶ Nut fastening for motor & contactor

1.Holding the lower nut on the stub and fastening the upper nut clockwise.
2.The torque setting for nut is 14 N-m/124 lb-in.



Warning

- The winch is not intended to be used in any manner for the movement or lifting of personnel.
- The rated line pull shown is based on the first layer of rope on the drum.
- The rope winding on the drum shall remain 10 wraps from the drum to support the rated load.
- Manufacturer is not responsible for the results of misuse, misapplication, faulty installation or abuse of synthetic rope in any way.

Parts List

Item No.	Description	Part No.	Qty
1	Waterproof motor w/housing 12V	883544	1
2	Forward Tie bar kit	882521	1
3	Reverse Tie bar kit	882522	1
4	Motor coupling	880005	1
5	Drum bushing	880006	2
6	Drum kit	881521	1
7	Gearbox support rack	882523	1
8	Grounding lead	880009	1
9	Synthetic rope	883248	1
10	1st shaft	880011	1
11	3rd ring gear kit	880114	1
12	3rd stage carrier	880115	1
13	2nd stage carrier	880116	1
14	1st stage carrier	880117	1
15	1st & 2nd ring gear	880118	1
16	1st pinion	880119	1
17	Clutch kit	881564	1
18	Gear box kit	882524	1
19	Cone brake disc kit	880122	1
20	Brake clutch base	881100	1
21	Brake cover kit	882525	1
22	Hawse fairlead	883410	1
23	Mounting hardware	880024	1
24	Remote control	880126	1
25	Handsaver strap	880026	1
26	Control box 12V	883613	1
26-1	Remote socket kit 12V	881491	1
26-2	Control pack 12V	883615	1
26-2-1	Wireless receiver	882800	1
26-3	Wireless transmitter	883822	1
27	Sling hook	882477	1

Winch Assembly



2022/02/16 Ver:11