

Model: Seal Slim 9.5s

PN: 295014 12V DC

## Introduction

#### ▶ Feature

Line pull: 4,309 kg / 9,500 lb synthetic rope first layer Synthetic rope: 10 mm × 30.5 m (3/8"×100') synthetic rope

Brake: Patented cone brake holds full load
Clutch: Turn the L-handle for rapid rope payout
Control: Handheld pendant switch powers the winch

#### ▶ Unpacking

Winch assembly	1 pc
· Control box	1 рс
• Remote control	1 pc
Synthetic rope with sling hook	1 pc
Hawse fairlead	1 pc
• 1.8 m (6') 2 gauge battery lead	1 pc

# ► Read this manual carefully


You should carefully read and understand this manual before operating it. Careless winch operation may result in personal injury hazards or property damage.

#### Installation

Before using the winch, make sure all electrical components have no corrosion or damaged; the environment should be clear and dry.

# ► Winch and hawse fairlead mountings


- It is very important that the winch will be mounted on a flat and hard surface of mounting channel in order to make sure the motor, drum and gearbox housing are aligned correctly.
- Hawse fairlead does not mount to the winch directly.



- The synthetic rope shall be wound in an under-wound orientation only.
- Four (4) M10 x 1.50 pitch 10.9 grade with 63.8 N-m torque settings (maximum) high tensile steel bolts must be used in order to sustain the loads imposed on the winch mounting.
- Two (2) M10 x 1.50 pitch stainless steel bolts must be used for fastening the hawse fairlead into the mounting channel.


### ▶ Wiring Diagram

- Connect thermal sensor harness plug, control ground, and cable A/F1/F2 to the motor.
- Attach the ground lead firmly to the negative (–) battery terminal and power lead to the positive (+) battery terminal. The voltage drop for the winch motor must not exceed 10% of the nominal voltage of 12V DC.



## ▶ Nut fastening for motor & contactor

- 1. Holding the lower nut on the stub and fastening the upper nut clockwise.
- 2. The torque setting for nut is 14 N-m/124 lb-in.




# **Warning**

- The winch is not intended to be used in any manner for the movement or lifting of personnel.
- The rated line pull shown is based on the first layer of rope on the drum.
- The rope winding on the drum shall remain 10 wraps from the drum to support the rated load.
- Manufacturer is not responsible for the results of misuse, misapplication, faulty installation or abuse of synthetic rope in any way.

# **Parts List**

Item No.	Description	Part No.	Qty
1	Waterproof motor w/housing 12V	883576	1
2	Tie bar kit	883132	1
3	Motor coupling	880005	1
4	Drum bushing	880006	2
5	Drum kit	881521	1
6	Gearbox support rack	883578	1
7	Grounding lead	880009	1
8	Synthetic rope	883248	1
9	1 <sup>st</sup> shaft	880011	1
10	3 <sup>rd</sup> ring gear kit	880114	1
11	3 <sup>rd</sup> stage carrier	880115	1
12	2 <sup>nd</sup> stage carrier	880116	1
13	1 <sup>st</sup> stage carrier	880117	1
14	1 <sup>st</sup> & 2 <sup>nd</sup> ring gear	880118	1
15	1 <sup>st</sup> pinion	880119	1
16	Clutch kit	883236	1
17	Gear box kit	882524	1
18	Cone brake disc kit	880122	1
19	Brake clutch base	881100	1
20	Brake cover kit	882525	1
21	Mounting hardware	880024	1
22	Remote control	880126	1
23	Handsaver strap	880026	1
24	Control box 12V	881164	1
24-1	Remote socket kit 12V	881373	1
24-2	Control pack 12V	881400	1
25	Sling hook	882477	1
26	Hawse fairlead	883410	1

# **Winch Assembly**



2023/03/06 Ver:01