

COMEUP WINCH

Model: Seal Slim 12.5

PN: 295042 12V DC

Introduction

► Feature

- Line pull: 5,670 kg / 12,500 lb wire rope first layer
- Wire rope: 9.5 mm × 25 m (3/8"×82') galvanized aircraft A7 × 19
- Brake: Patented cone brake holds full load
- Clutch: Turn the L-handle for rapid rope payout
- Control: Handheld pendant switch powers the winch

► Unpacking

- Winch assembly..... 1 pc
- Control box..... 1 pc
- Remote control..... 1 pc
- Wire rope with Clevis hook..... 1 pc
- Roller fairlead..... 1 pc
- 1.8 m (6') 2 gauge battery lead..... 1 pc

► Read this manual carefully


You should carefully read and understand this manual before operating it. Careless winch operation may result in personal injury hazards or property damage.

Installation

Before using the winch, make sure all electrical components have no corrosion or damaged; the environment should be clear and dry.

► Winch and roller fairlead mountings


- It is very important that the winch will be mounted on a flat and hard surface of mounting channel in order to make sure the motor, drum and gearbox housing are aligned correctly.
- Roller fairlead does not mount to the winch directly.



- The wire rope shall be wound in an under-wound orientation only.
- Four (4) M10 x 1.50 pitch 10.9 grade with 63.8 N-m torque settings (maximum) high tensile steel bolts must be used in order to sustain the loads imposed on the winch mounting.
- Two (2) M12 x 1.75 pitch 8.8 grade with 76 N-m torque settings (maximum) high tensile steel bolts must be used for fastening the roller fairlead into the mounting channel.


► Wiring Diagram

- Connect thermal sensor harness plug, control ground, and cable A/F1/F2 to the motor.
- Attach the ground lead firmly to the negative (-) battery terminal and power lead to the positive (+) battery terminal. The voltage drop for the winch motor must not exceed 10% of the nominal voltage of 12V DC.



► Nut fastening for motor & contactor

1. Holding the lower nut on the stub and fastening the upper nut clockwise.
2. The torque setting for nut is 14 N-m/124 lb-in.



Warning

- The winch is not intended to be used in any manner for the movement or lifting of personnel.
- The rated line pull shown is based on the first layer of rope on the drum.
- The rope winding on the drum shall remain 5 wraps from the drum.

Parts List

| Item No. | Description | Part No. | Qty |
|----------|---|----------|-----|
| 1 | Waterproof motor w/housing 12V | 883576 | 1 |
| 2 | Tie bar kit | 883132 | 1 |
| 3 | Motor coupling | 880005 | 1 |
| 4 | Drum bushing | 880006 | 2 |
| 5 | Drum kit | 881521 | 1 |
| 6 | Gearbox support rack | 883578 | 1 |
| 7 | Grounding lead | 880009 | 1 |
| 8 | Wire rope | 881994 | 1 |
| 9 | 1 st shaft | 881523 | 1 |
| 10 | 3 rd ring gear kit | 883900 | 1 |
| 11 | 3 rd stage carrier | 881960 | 1 |
| 12 | 2 nd stage carrier | 881961 | 1 |
| 13 | 1 st stage carrier | 881962 | 1 |
| 14 | 1 st & 2 nd ring gear | 881963 | 1 |
| 15 | 1 st pinion | 881964 | 1 |
| 16 | Clutch kit | 883236 | 1 |
| 17 | Gear box kit | 884307 | 1 |
| 18 | Cone brake disc kit | 880122 | 1 |
| 19 | Brake clutch base | 881100 | 1 |
| 20 | Brake cover kit | 882537 | 1 |
| 21 | Mounting hardware | 880024 | 1 |
| 22 | Remote control | 880126 | 1 |
| 23 | Handsaver strap | 880026 | 1 |
| 24 | Control box 12V | 881164 | 1 |
| 24-1 | Remote socket kit 12V | 881373 | 1 |
| 24-2 | Control pack 12V | 881400 | 1 |
| 25 | Clevis hook | 881996 | 1 |
| 26 | Roller fairlead | 880023 | 1 |

Winch Assembly

